



Radiant Gas Fireplaces



Models 530XAN/XAP (logs) Models 530XCN/XCP (coals) Direct Vent Gas Fireplace Heater Installation & Operating Instructions

*INSTALLER: Leave this manual with the appliance.
CONSUMER: Retain this manual for future reference.*

This manual contains instructions to install the **ENGINE ONLY**. A front trim kit is **REQUIRED** to install the engine as it affects the framing cavity and position of the engine. **Refer to the manual supplied with the front for framing and finishing.**

Please read this manual BEFORE installing and operating this appliance.

WARNING: If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light the appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

Installation and service must be performed by a qualified installer, service agency or the gas supplier.

This appliance may be installed in an after-market permanently located, manufactured (mobile) home where not prohibited by local codes.

This appliance is only for use with the type of gas indicated on the rating plate. This appliance is not convertible for use with other gases, unless a certified kit is used.

This appliance is a domestic room-heating appliance. It must not be used for any other purposes such as drying clothes, etc.

This appliance is suitable for installation in a bedroom or bed sitting room.

Massachusetts: The piping and final gas connection must be performed by a licensed plumber or gas fitter in the State of Massachusetts. Also, see Carbon Monoxide Detector requirements under "Safety and Warning Information" on page 5.

Manufactured by
MILES INDUSTRIES LTD.
British Columbia, Canada
www.milesfireplaces.com



Thank You ...

For purchasing a Valor by Miles Industries. Your new radiant gas heater is a technical appliance that must be installed by a qualified dealer. Each Valor is fully tested during the production process for your safety and comfort.

Your unit has been professionally installed by:

Dealer Name _____

Phone Number _____

Should you encounter an operational problem, call your dealer immediately. Do not try to repair the unit as you may cause an injury or damage the fireplace.

The information contained in this installation manual is believed to be correct at the time of printing. Miles Industries Ltd. reserves the right to change or modify any information or specifications without notice. Miles Industries Ltd. grants no warranty, implied or stated, for the installation or maintenance of your heater, and assumes no responsibility for any consequential damage(s).



We recommend that our gas hearth products be installed and serviced by professionals who are certified in the United States by NFI (National Fireplace Institute®).

WARNING



**HOT GLASS WILL
CAUSE BURNS.
DO NOT TOUCH GLASS
UNTIL COOLED.
NEVER ALLOW CHILDREN
TO TOUCH GLASS.**

**Designed and Manufactured by
Miles Industries Ltd.**

190 – 2255 Dollarton Highway, North Vancouver B.C., CANADA V7H 3B1

Tel. 604-984-3496 Fax 604-984-0246

www.milesfireplaces.com

© Copyright Miles Industries Ltd., 2007

Table of Contents

Safety and Warning Information	4
Specifications	7
Dimensions, Clearance and Framing	8
Horizontal Termination Locations.....	9
Horizontal Termination Venting Configurations	10
Horizontal Termination Installations.....	12
Vertical Termination Venting Configurations.....	13
Vertical Termination Installations	15
Appliance Preparation	17
Air Restrictors Installation.....	20
Remote Control Installation.....	21
Gas Supply Installation.....	22
Aeration Setting Check	23
Ceramic Walls Installation	23
Ceramic Logs Installation.....	24
Ceramic Coals Installation.....	25
Window Refitting and Checking.....	26
Operation Checks.....	26
Owner's Information.....	27
Lighting Instructions.....	30
Options	31
Approved Venting Components.....	32
Warranty	34
Replacement Parts	35

Safety and Warning Information

READ and **UNDERSTAND** all instructions carefully before starting the installation. **FAILURE TO FOLLOW** these installation instructions may result in possible fire hazard and will void the warranty.

Prior to the first firing of the fireplace, **READ** the Owner's Information section of this manual.

DO NOT USE this appliance if any part has been under water. Immediately, **CALL** a qualified service technician to inspect the unit and to replace any part of the control system and any gas control that has been under water.

THIS UNIT IS NOT FOR USE WITH SOLID FUEL.

Installation and repair should be **PERFORMED** by a qualified service person. The appliance and venting system should be **INSPECTED** before initial use and at least annually by a professional service person. More frequent cleaning may be required due to excessive lint from carpeting, bedding, etc. It is **IMPERATIVE** that the unit's control compartment, burner, and circulating air passageways **BE KEPT CLEAN** to provide for adequate combustion and ventilation air.

Always **KEEP** the appliance clear and free from combustible materials, gasoline, and other flammable vapors and liquids.

NEVER OBSTRUCT the flow of combustion and ventilation air. Keep the front of the appliance **CLEAR** of all obstacles and materials for servicing and proper operation.

Due to the high temperature, the appliance should be **LOCATED** out of traffic areas and away from furniture and draperies. Clothing or flammable material **SHOULD NOT BE PLACED** on or near the appliance.

Children and adults should be **ALERTED** to the hazards of high surface temperature and should **STAY AWAY** to avoid burns or clothing ignition. Young children should be **CAREFULLY SUPERVISED** when they are in the same room as the appliance.

This unit **MUST** be used with a vent system as described in this installation manual. **NO OTHER** vent system or components **MAY BE USED**.

This gas fireplace and vent assembly **MUST** be vented directly to the outside and **MUST NEVER** be attached to a chimney serving a separate solid fuel burning appliance. Each gas appliance **MUST USE** a separate vent system. Common vent systems are **PROHIBITED**.

INSPECT the external vent cap on a regular basis to make sure that no debris, plants, trees, shrubs are interfering with the air flow.

The glass door assembly **MUST** be in place and sealed before the unit can be placed into safe operation.

DO NOT OPERATE this appliance with the glass door removed, cracked, or broken. Replacement of the glass door should be performed by a licensed or qualified service person. **DO NOT** strike or slam the glass door.

The glass door assembly **SHALL ONLY** be replaced as a complete unit, as supplied by the fireplace manufacturer. **NO SUBSTITUTE** material may be used.

DO NOT USE abrasive cleaners on the glass door assembly. **DO NOT ATTEMPT** to clean the glass door when it is hot.

TURN OFF the gas before servicing this appliance. It is recommended that a qualified service technician perform an appliance check-up at the beginning of each heating season.

Any safety screen or guard removed for servicing **MUST BE REPLACED** before operating this appliance.

DO NOT place furniture or any other combustible household objects within 36" of the fireplace front.

BE CAREFUL not to put any decorating objects sensitive to heat to close above or around the fireplace as it gets very hot when operating.

DO NOT use this heater as a temporary source of heat during construction.

NOTE: When operating your new fireplace for the first time, some vapors may be released due to the burning of curing compounds used in the manufacture of the appliance. They may cause a slight odor and could cause the flames to be the full height of the firebox, or even slightly higher, for the first few hours of operation. It is also possible that these vapors could set off any smoke detection alarms in the immediate vicinity. These vapors are quite normal on new appliances. We recommend opening a window to vent the room. After a few hours use, the vapors will have disappeared and the flames will be at their normal height.

Safety and Warning Information

State of California. Proposition 65 Warning. Fuels used in gas, wood-burning or oil fired appliances, and the products of combustion of such fuels, contain chemicals known to the State of California to cause cancer, birth defects and other reproductive harm. California Health & Safety Code Sec. 25249.6.

State of Massachusetts Carbon Monoxide Detector/Vent Terminal Signage Requirements

For all side wall horizontally vented gas fueled equipment installed in every dwelling, building or structure used in whole or in part for residential purposes, including those owned or operated by the Commonwealth and where the side wall exhaust vent termination is less than seven (7) feet above finished grade in the area of the venting, including but not limited to decks and porches, the following requirements shall be satisfied:

1. **INSTALLATION OF CARBON MONOXIDE DETECTORS.** At the time of installation of the side wall horizontal vented gas fueled equipment, the installing plumber or gas fitter shall observe that a hard wired carbon monoxide detector with an alarm and battery back-up is installed on the floor level where the gas equipment is to be installed. In addition, the installing plumber or gas fitter shall observe that a battery operated or hard wired carbon monoxide detector with an alarm is installed on each additional level of the dwelling, building or structure served by the side wall horizontal vented gas fueled equipment. It shall be the responsibility of the property owner to secure the services of qualified licensed professionals for the installation of hard wired carbon monoxide detectors.

a. In the event that the side wall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the hard wired carbon monoxide detector with alarm and battery back-up may be installed on the next adjacent floor level.

b. In the event that the requirements of this subdivision can not be met at the time of completion of installation, the owner shall have a period of thirty (30) days to comply with the above requirements; provided, however, that during said thirty (30) day period, a battery operated carbon monoxide detector with an alarm shall be installed.

2. **APPROVED CARBON MONOXIDE DETECTORS.** Each carbon monoxide detector as required in accordance with the above provisions shall comply with NFPA 720 and be ANSI/UL 2034 listed and IAS certified.

3. **SIGNAGE.** A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, "GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS".

4. **INSPECTION.** The state or local gas inspector of the side wall horizontally vented gas fueled equipment shall not approve the installation unless, upon inspection, the inspector observes carbon monoxide detectors and signage installed in accordance with the provisions of 248 CMR 5.08(2)(a)1 through 4.

(b) **EXEMPTIONS:** The following equipment is exempt from 248 CMR 5.08(2)(a)1 through 4:

1. The equipment listed in Chapter 10 entitled "Equipment Not Required To Be Vented" in the most current edition of NFPA 54 as adopted by the Board; and

2. Product Approved side wall horizontally vented gas fueled equipment installed in a room or structure separate from the dwelling, building or structure used in whole or in part for residential purposes.

Safety and Warning Information

(c) MANUFACTURER REQUIREMENTS - GAS EQUIPMENT VENTING SYSTEM PROVIDED. When the manufacturer of Product Approved side wall horizontally vented gas equipment provides a venting system design or venting system components with the equipment, the instructions provided by the manufacturer for installation of the equipment and the venting system shall include:

1. Detailed instructions for the installation of the venting system design or the venting system components; and
2. A complete parts list for the venting system design or venting system.

(d) MANUFACTURER REQUIREMENTS - GAS EQUIPMENT VENTING SYSTEM NOT PROVIDED. When the manufacturer of a Product Approved side wall horizontally vented gas fueled equipment does not provide the parts for venting the flue gases, but identifies “special venting systems”, the following requirements shall be satisfied by the manufacturer:

1. The referenced “special venting system” instructions shall be included with the appliance or equipment installation instructions; and
2. The “special venting systems” shall be Product Approved by the Board, and the instructions for that system shall include a parts list and detailed installation instructions.

(e) A copy of all installation instructions for all Product Approved side wall horizontally vented gas fueled equipment, all venting instructions, all parts lists for venting instructions, and/or all venting design instructions shall remain with the appliance or equipment at the completion of the installation.

Specifications

Approvals and Codes

This appliance is certified to ANSI Z21.88a–2007/CSA 2.33a–2007 *Vented Gas Fireplace Heater Standard* for use in Canada and USA.

The appliance complies with CGA P.4.1, *Testing method for measuring annual fireplace efficiencies*.

The installation must conform with local codes or, in the absence of local codes with the *National Fuel Gas Code*, ANSI Z223.1 or the *Natural Gas and Propane Installation Code* CAN/CGA-B149. Only qualified licensed or trained personnel should install the appliance.

The appliance, when installed, must be electrically grounded in accordance with local codes or, in the absence of local codes, with the *National Electrical Code*, ANSI/NFPA 70 or the *Canadian Electrical Code*, CSA C22.1.

Ratings

	NG	LPG
Altitude (Ft)	0-4500 *	
Input Max. (Btu/h)	20,500	19,000
Input Min (Btu/h)	6,000	11,600
Manifold pressure (in.w.c.)	3.5 – 3.9	10.3 – 10.7
Min. Supply pressure (in. w.c.)	5	11
Max. Supply pressure (in. w.c.)	10.5	14

*Tested to CAN/CGA - 2.17 *Gas fired appliances for use at high altitudes*. In USA, installations may require deration over 2000'—Check local codes.

Front Trims

Various fronts are available for the 530X engine. This engine may be installed as a free standing, zero clearance or insert application depending on which style front trim is selected. **The front trim style affects the framing cavity, clearances and position of the engine. A front trim kit is required for all applications and should be on site when the engine is installed** as the parts to make the engine suitable for zero clearance are supplied with the front trim kits (except 549 front).

Fuel Beds

The 530X engine is available in either natural gas or propane gas and comes equipped with either a simulated log or coal fuel bed in either fuel. A pebble set is also offered as an optional feature. See *Options* section in this manual.

Venting options

The 530X engine unit is supplied standard with a rear direct vent outlet and may be converted to a top direct vent outlet with no extra parts required—see *Conversion to Top Outlet for Solid Direct Vent Co-axial Piping* in the *Appliance Preparation* section further on in this manual.

Direct vent installations (solid piping)

A list of all approved venting accessories is shown on pages 32–33 of this manual.

Direct Vent Co-Linear Installations for Free Standing or Recessed Installations (flexible piping)

Converts the appliance outlet collars to accept two 3" dia. flexible liners for installation into existing solid-fuel burning fireplaces and chimneys. Requires a co-linear adapter at the appliance and either a co-linear terminal or co-linear-to-co-axial terminal at the top of the chimney. A list of approved venting accessories is shown on pages 32–33 of this manual.

Gravity Vent Installations – For President Free Standing only 552BVX

Converts this appliance from a direct vent fireplace heater to a gravity vent fireplace heater for use with a 4" "B" type vent. Use this installation manual in conjunction with the installation manual supplied with the 552BVX kit.

Specifications

Wall Thickness

The appliance vent is suitable for penetrating a combustible wall up to 14" (36cm) thick. A non-combustible wall can be any thickness up to the maximum horizontal run of vent pipe allowed for the particular installation—see *Horizontal Termination Venting Configurations* section.

Supply Gas

Heater engine 530XAN /XCN is used for Natural gas installations.

Heater engine 530XAP/XCP is used for Propane gas installations.

The supply pressure must be between the limits shown in the *Ratings* table on the previous page.

The supply connection is 3/8"NPT female.

The opening for the gas supply line is at the rear left corner of the appliance.

Controls

The unit is supplied standard with a battery operated, hand-held remote control and receiver which has the ability to adjust the gas input of the unit between the pilot setting and the maximum input. The pilot light must be manually lit at the valve and may be left on or turned off with each use to save energy. The remote control provides full thermostatic or manual operation with the option of programming thermostat function between certain times of the day. Manual operation of the valve is also possible should the batteries or remote control fail.

Electrical


The unit does not require an electrical power source unless fitted with an optional circulating fan.

Dimensions, Clearance and Framing

The dimensions, clearances and framing vary with each applications and with the front trim installed. Refer to the installation instructions of the front trim chosen for more information.

Horizontal Termination Locations

- The vent terminal must be located on an outside wall or through the roof.
- This direct vent appliance is designed to operate when an undisturbed airflow hits the outside vent terminal from any direction.
- The minimum clearances from this terminal that must be maintained when located on an outside wall are shown in figure below. Any reduction in these clearances could result in a disruption of the airflow or a safety hazard. Local codes or regulations may require greater clearances.
- The vent terminal must not be recessed into a wall or siding.
- The vent terminal should be positioned where any snowdrifts will not cover it.
- Sidewall vent terminations within 7' of grade require a terminal guard when using the 551DVK.



KEY	VENT TERMINAL LOCATIONS - MINIMUM DISTANCES	MIN. CLEARANCES	
		in	cm
A	Clearance above grade, verandah, porch, deck or balcony	12	30
B	Clearance to window or door that may be opened	12	30
C	Clearance to permanently closed window (recommended to prevent condensation on window)	12	30
D	Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (60 cm) from the center-line of the terminal	18	46
E	Clearance to unventilated soffit	12	30
F	Clearance to outside corner	12	30
G	Clearance to inside corner	12	30
H	Horizontal clearance to center-line of meter/regulator assembly located within 15 feet (4.6 m) below the terminal	36	90
I	Clearance to service regulator vent outlet	36	90
J	Clearance to non-mechanical air supply inlet to the building or the combustion air inlet to any other appliance	12	30
K	Clearance to a mechanical air supply inlet	72	180
L	Clearance above paved sidewalk or a paved driveway located on public property. Note: A vent must not terminate directly above a sidewalk or paved driveway, which is located between two single-family dwellings and serves both dwellings.	84	210
M	Clearance under a verandah, porch, deck or balcony. Only permitted if veranda, porch, deck or balcony is fully open on a minimum of 2 sides beneath the floor.	12	30

Note: Local codes and regulations may require different clearances.


Horizontal Termination Venting Configurations

See venting accessories list on pages 32–33 for allowable components.

Rear Outlet—No Vertical Rise


Flat on the Wall

- Maximum 26" horizontal pipe length;
- 817VAK Vent Collar Adapter required if using other than Valor's 551DVK pipe with termination;
- Terminal Guard may be required if terminating within 7'0" of grade or where accessible.



In Corner—No Vertical Rise

- Maximum 1 x 45° elbow allowed;
- Maximum 18" horizontal pipe length;
- Terminal guard may be required if terminating within 7'0" of grade or where accessible.




Horizontal Termination Venting Configurations

See venting accessories list on pages 32–33 for allowable components.

Rear Outlet w/Vertical Rise—Horizontal Termination

- 817VAK Vent Collar Adapter required;
- Maximum 2 x 90° elbows allowed (or equivalent: 2 x 45° elbows = 1 x 90° elbow);
- Terminal guard may be required if terminating within 7'0" of grade or where accessible.

	Minimum	Maximum
D: Vertical pipe run	12" (30 cm)	8' (244 cm)
E: Horizontal pipe run (Total before and after elbows) E ¹ + E ²	-	4'-6" (137 cm)
F: Clearance to combustible materials above horizontal pipe run	2-5/8" (6.7 cm)	-
G: Clearance to combustible materials below horizontal pipe run	1-5/16" (3.3 cm)	-
H: Clearance to combustible materials all round vertical pipe run and at sides of horizontal pipe run	1-5/16" (3.3 cm)	-




Top Outlet w/Vertical Rise—Horizontal Termination

See *Conversion to Top Outlet for Solid Direct Vent Co-axial Piping in Appliance Preparation* section for conversion to top outlet;


- 817VAK Vent Collar Adapter required;
- Maximum 2 x 90° elbows allowed (or equivalent: 2 x 45° elbows = 1 x 90° elbow);
- Terminal guard may be required if terminating within 7'0" of grade or where accessible.

	Minimum	Maximum
D: Vertical pipe run (total)	9" (23 cm)	8' (244 cm)
E: Horizontal pipe run (total)	-	4'-6" (137 cm)
F: Clearance to combustible materials above horizontal pipe run	2-5/8" (6.7 cm)	-
G: Clearance to combustible materials below horizontal pipe run	1-5/16" (3.3 cm)	-
H: Clearance to combustible materials all round vertical pipe run and at sides of horizontal pipe run	1-5/16" (3.3 cm)	-



Horizontal Termination Installations

- The 530 heater may be installed using components from a variety of manufacturers listed on pages 32–33.
- Allowable vent configurations and clearances for the 530 heater are listed in this manual and apply for all vent components listed on pages 32–33. For details of component installation, follow instructions packaged with each component.
- The 530 heater is supplied with a smooth 4⁷/₁₆-5⁷/₈" co-axial collar intended to accept the Valor 551DVK Vent Termination with pipe attached. All other applications will require an 817VAK Vent Adapter to convert the collar to a twist-lock type collar. All other manufacturers' components listed (including Valor 551DVK) have designed their components to fit this twist-lock type collar.
- Do not mix components from different manufacturers with the exception of the final piece through the wall which may be a Valor 551DVK Vent Termination with pipe attached.
- Do not cut pipe lengths, except the 551DVK which may be cut to desired length. Use adjustable lengths otherwise.



Fix the Vent Unit or 817VAK to Appliance

- Fit the vent unit or 817VAK over the inlet and outlet collars of the appliance, pushing on firmly. If using the 551DVK, ensure that the end of the pipe is cut cleanly and square. Rotate the pipe to ensure that the seam will pass through notch in the wall plates and that the drain hole is at the bottom.
- Drill through the outer tube and the appliance collar with #6 screws. *Make sure the drill does not penetrate the inner pipe.*
- Secure the vent unit or 817VAK to the outer collar with two #6 thread-cutting screws supplied.

Through the wall details


- If the wall has combustible material, appropriate insulation shielding or wall thimble must be used specific to the manufacturer of the venting. In any case, a minimum of 10" x 10" or 10" diameter hole is required. If the wall is totally non-combustible (e.g. masonry block or concrete) mark for a 7" circular hole. In both cases, the center of the hole should line up with the center line of the horizontal vent.
- See *Horizontal Termination Locations* section for allowable vent terminal locations.
- Avoid structural elements when locating the hole through the wall.

Important Installer Notice – Weather Sealing & Vapor Barriers

It is the installer's responsibility to ensure that vent installations through exterior walls are caulked and weatherproofed in such a manner as to:

- Prevent rain water from entering the wall from the weather side by adequately caulking the outer vent plate to the exterior wall surface.
- Prevent moisture inside the home from penetrating into the wall structure by ensuring the inside wall plate is adequately sealed to the inside vapor barrier.
- Prevent rain water and moisture from entering the walls by sealing the joints between the outer vent tube and the inner and outer wall plates.

We recommend the use of a high quality polyurethane sealant.




Vertical Termination Venting Configurations

See venting accessories list on pages 32–33 for allowable components.

Rear Outlet through Roof (Co-axial Pipe)


- 817VAK Vent Collar Adapter required;
- Maximum 2 x 45° elbows allowed for offsetting;
- Various other ceiling or roof items may be necessary depending on the particular installation.



Top Outlet through Roof (Co-axial Pipe)

See *Conversion to Top Outlet for Solid Direct Vent Co-axial Piping* in *Appliance Preparation* section for conversion to top outlet.

- 817VAK Vent Collar Adapter required;
- Maximum offset 4'6";
- Maximum 2 x 90° elbows allowed for offsetting (or equivalent: 2 x 45° elbows = 1 x 90° elbow);
- Various other ceiling or roof items may be necessary depending on the particular installation.




Vertical Termination Venting Configurations

See venting accessories list on pages 32–33 for allowable components.


Co-linear Venting into Existing Solid-Fuel Burning Fireplaces and Chimneys

Co-linear adapter may be installed as top or rear outlet—see *Conversion to Top Outlet for Solid Direct Vent Co-axial Piping* in *Appliance Preparation* section for conversion to top outlet.


- Co-linear and co-axial venting may be combined in a single venting system provided conversion is done only once using approved components and maintaining proper clearances;
- 3" liners may only be installed into solid-fuel burning fireplaces and chimney systems (no combustible construction);
- The appliance must not be connected to a chimney flue serving a separate solid-fuel burning appliance.




Co-Linear installation into existing F/P




556CLA Kit




556CLA Rear Mounted



556CLA Top Mounted




559CLT Co-Linear Terminal




559FSK Flashing Kit


Alternate to 556CLA/559CLT/559FSK Conversion




Co-Axial to Co-Linear Adapter



Terminal Cap



Co-Linear to Co-Axial Adapter





Flashing

Vertical Termination Installations

See venting accessories list on pages 32–33 for allowable components.

All Co-axial Vent Installations

- The 530 heater may be installed using components from a variety of manufacturers listed on pages 32–33.
 - Allowable vent configurations and clearances for the 530 heater are listed in this manual and apply for all vent components listed on pages 32–33. For details of component installation, follow instructions packaged with each component.
 - The 530 heater is supplied with a smooth 4”/6-5/8” co-axial collar. All vertical termination applications will require an 817VAK Vent Adapter to convert the collar to a twist-lock type. All other manufacturers’ components listed have designed their components to fit the twist-lock type collar.
 - Do not mix components from different manufacturers.
 - Do not cut pipe lengths. Use adjustable lengths. Check the roof pitch to determine which roof flashing will be needed.
 - The minimum clearances to combustible materials all round the vent pipes must be in accordance with the dimensions shown previously in this manual.
1. If using rear vent connection to the appliance, fit a 90° elbow to the appliance vent adapter.
 2. Place the appliance in its proper location.
 3. Drop a plumb from the ceiling to the center of the appliance vent opening. Mark the position on the ceiling. Drill a small hole at the marked position.
 4. Determine the position where the vent will pass through the roof. If directly above the position where it penetrates the ceiling, drop a plumb from the roof to the small hole in the ceiling and mark the roof at this spot. If rafters or other obstructions will prevent a vertical exit or if clear attic space is desired, the roof outlet can be offset using elbows. Drill a small hole at the marked position.
 5. A ceiling firestop must be installed at the second floor and higher floors. A ceiling support should be used below the flat ceiling. To install the firestop and support, cut and frame a 10” (254mm) square hole centered on the small hole previously drilled.
 6. Fit vent accessory elbows and pipe lengths as required up through ceiling support boxes and firestops. If installation includes offset, support the offsetting pipes every 3 feet (1m) with wall straps.
 7. Cut a hole in the roof centered on the small hole. The hole must allow for the minimum clearances to combustible materials
 8. Fit pipe lengths through the roof. Fit roof flashing securing it with roofing nails.
 9. Fit storm collar and termination cap.
 10. FS installations. Secure the appliance to the floor or wall if necessary.




Vertical Termination Installations

See venting accessories list on pages 32–33 for allowable components.

Co-linear Vent Installations


1. The size of the fireplace cavity required to insert the 530 engine varies with the style of front trim chosen. Refer to the front trim installation manual for required dimensions.
2. Place the appliance (fitted with the co-linear adapter) near the fireplace opening but allow space for manipulating the chimney liners on to the appliance.
3. Drop the 3" dia. flexible liners into the chimney from outside.
4. Fit the liners to the co-linear adapter paying attention to inlet and exhaust and move the appliance to its proper position. Be aware of the minimum liner bend radius and maximum liner horizontal run as shown on page 14 in this manual.
5. Fit the termination kit and flashing if required to the exterior of the chimney.
6. Secure the appliance to the floor or wall if necessary.



Appliance Preparation

Window Removal


1. Release the top of the window by pulling forward and rotating outwards the two bars at the top corners.
2. Unscrew the two spring-loaded bolts securing the bottom of the window.
3. Carefully lift the window. Keep the window and bolts in a safe place.
4. Remove the packaged ceramic Bricks/Logs/Coals from firebox.



Check Ignition Spark



The pilot burner and electrode unit is at the left end of the burner.

Push in the lighting knob and turn counter-clockwise through the "IGN" position to "PILOT". A spark should flash across from the pilot electrode to the pilot burner shield.



Burner Module Removal

It may be desirable to remove the burner module to gain access for gas fitting, to install a fan kit, or to fasten the unit to the floor or plinth supplied with the zero clearance fronts.





Appliance Preparation

Conversion to Top Outlet for Solid Direct Vent Co-axial Piping

If installing with rear vent outlet, go to next step.

1. Remove the top plate and seal by unscrewing 12 screws. Keep the seal, plate and screws for fitting to the back.
2. Remove the rear outer vent collar and seal by unscrewing 12 screws.
3. Remove the rear inner vent collar and seal by unscrewing 8 screws.
4. To make sure that the collars are axially aligned, fit the adapter #817VAK over the outer vent collar.
5. Position the inner collar and seal vertically inside the top of the appliance. Drop the outer collar with adapter over the inner collar to ensure alignment. Secure the inner collar with 8 screws and the outer collar with 12 screws.
6. Fit the plate and seal (which was previously removed from the top) to the back of the appliance with 12 screws.




Appliance Preparation

Vent Outlet Preparation for Co-axial Installations using Non-Valor Vent Components


If installing straight off the back venting with Valor terminal kit #551DVK only, ignore this step:

1. Fit the adapter #817VAK over the appliance vent collars pushing on firmly. Align the adapter so that the seam on horizontal pipes is not at the bottom—check by temporarily fitting a pipe.
2. Drill through the adapter outer tube and appliance outer collar for #6 screws. *Make sure that the drill does not penetrate the inner tubes.*
3. Secure the adapter to the outer collar with two #6 thread cutting screws supplied.



Co-linear Conversion using Listed Generic Adapter Box

1. Fit the adapter #817VAK over the appliance vent collars pushing on firmly.
2. Fit and fully twist-lock the co-axial-to-co-linear adapter to the #817VAK adapter.
3. Keeping the connector and adapter fully twist-locked, rotate them so that the air inlet collar on the connector is at the bottom.
4. Drill through the adapter outer tube and appliance outer collar for #6 screws. *Make sure the drill does not penetrate the inner tubes.*
5. Secure the adapter to the outer collar with two #6 thread cutting screws supplied.




Co-linear Conversion using Valor 556CLA Co-linear Adapter


(Note: Instructions may vary as 556CLA may be installed on Top or Back of Heater.)

1. Remove the blank plate and gasket to gain access to the exhaust spigot. Retain the plate and gasket for re-use later.
2. Remove the existing outer intake plate. Retain the gasket only for re-use.
3. Remove the existing exhaust spigot—the gasket below should remain on the heater.
4. Install the new co-linear exhaust spigot re-using existing screws. Ensure all screws are reinstalled tightly.
5. Install the new co-linear outer plate (note: up/down front/back orientation on drawing) re-using existing gasket and screws. Use 6 additional screws supplied to seal outer plate to gasketed flange of exhaust spigot. Connect 3" dia. flex liners directly to outer plate collars using sheet metal screws.

Note: "exhaust" & "intake" must correspond with roof termination.



Remove existing outlet



Replace existing outlet with 556CLA kit

Air Restrictors Installation

Attaching Air Restrictors—Appliances with Vertical Vent Rise Only

- No restrictors are required for appliances which only have a horizontal vent run.
- Restrictors for co-linear applications are the same as required for co-axial of same height—see table below.
- There are three types of restrictors supplied with each #530 engine unit. They are slightly different in size. They can be identified by the number printed on them. The restrictors cover part of the openings in the firebox rear wall ports. Each restrictor can be fitted at either Maximum or Minimum port opening.





Types 1, 2 and 3 are supplied with ceramic log appliances.

Types 4, 5, and 6 are supplied with ceramic coal appliances.

The correct restrictors to be fitted for each type of installation are shown in the table below.

- To fit the restrictors, remove the center screws from the rear ports and fit the restrictors using these screws.
- To set the restrictors at maximum port opening, slacken the bottom screws in the ports, slide the restrictors down as far as possible and tighten the screws over the restrictors.
- To set the restrictors at minimum port opening, slide the restrictors up as far as possible and tighten the screws.
- With the largest restrictors, the upper screws may need to be slackened to allow the restrictors to go under the screw heads.

Vent terminal	Vertical vent pipe run	Use restrictor type		Port opening
		Logs	Coals	Set at
Horizontal through wall (with vertical rise)	Less than 2' (61 cm)	1	4	Maximum
	From 2' (61 cm) but less than 4' (122 cm)	1	4	Minimum
	From 4' (122 cm) but less than 6' (183 cm)	2	5	Maximum
	6' (183 cm) or more	2	5	Minimum
Vertical through roof	Less than 13' (396 cm)	3	6	Maximum
	13' (396 cm) or more	3	6	Minimum






Remote Control Installation

Caution! Do not connect the batteries to the remote control receiver until the wires are connected to the burner control unit, as a short circuit could result in the destruction of the electrical components.


- Connect the wiring harness to the receiver box, by pushing the wire connector on to the receiver circuit board. The plug will only go on one way so please ensure that the wires are pointing up and slot in the board is in line with the tab on the wiring harness plug
- Connect wires as shown below.
Please note that the “L” connectors are different sizes, the smaller one fits to the lower connection on the valve. The other wire connectors can be fitted to either terminal .
- Remove the remote control receiver lid.
- Fit four 1.5V batteries.
- Place the remote control receiver on the “Velcro” pad.
- Fit the 9V battery to the handset transmitter

Remote control operating instructions are on pages 28–29 of this manual and are supplied with the remote control kit.



Gas Supply Installation


- It's preferable to rough-in the gas line at this point before proceeding with the firebox installation.
- The appliance is supplied for supply gas connection at the rear left corner of the case. Supply line connection to the inlet pipe of the appliance is 3/8"NPT (female).
Alternatively, the appliance inlet pipe may be removed and the supply line routed directly to the control unit having a 3/8" NPT female thread. Take care not to torque the valve or damage the wire connectors on the valve. An isolating valve could be fitted within the appliance case. If the circulating fan is to be installed, be aware that the supply pipe should follow the route of the original appliance inlet pipe in order to clear the fan. If intending to fit an internal isolating valve, check that it will be clear of the fan.
- Use only new black iron or steel pipes or copper tubing if acceptable—check local codes. *Note that in USA, copper tubing must be internally tinned for protection against sulfur compounds.*
- Unions in gas lines should be of ground joint type.
- The gas supply line must be sized and installed to provide a supply of gas sufficient to meet the maximum demand of the appliance without undue loss of pressure.
- Sealant used must be resistant to the action of all gas constituents including LP gas. Sealant should be applied lightly to male threads to ensure excess sealant does not enter gas lines.
- The supply line should include a manual shut-off valve and union to allow the appliance to be disconnected for servicing.
- Pressure test the supply line for leaks.
- **The appliance and its individual shut-off valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 psig (3.5kPa).**
- **The appliance must be isolated from the gas supply piping system by closing its individual manual shut-off valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psig (3.5kPa).**
- Failure to either disconnect or isolate the appliance during pressure testing may result in regulator or valve damage. Consult your dealer in this case.
- The minimum supply pressure is given in *Specifications* section of this manual.
- All piping and connections must be tested for leaks after installation or servicing. All leaks must be corrected immediately.
- When testing for leaks:
 - Make sure that the appliance is turned off.
 - Open the manual shut-off valve.
 - Test for leaks by applying a liquid detergent or soap solution to all joints. Bubbles forming indicate a gas leak. **Never use an open flame to check for leaks.**
 - Correct any leak detected immediately.
- The pressure test tapping locations are shown in figure above. A built-in non-adjustable regulator controls the burner manifold pressure. The correct pressure range is shown in the table in the *Specifications* section of this manual. The pressure check should be made with the burner alight and at its highest setting. See *Lighting Instructions* section for full operating details.



Aeration Setting Check

The burner is equipped with an adjustable shutter to control primary aeration. The shutter is factory set at an aeration gap, which will give optimum performance for the vast majority of installations. In a few unusual installations, performance may be improved by adjusting the aeration. The need for adjustment should be determined by operating the appliance with the ceramic fuel effects and window installed. See the *Operation Checks* section further on in this manual for adjustment details.


The shutter setting is very critical. A change of 1/64" can make a substantial difference to the performance.



Ceramic Walls Installation








The 530 engine is provided with a set of reversible walls. One side shows the brick pattern and the reverse side shows a black vertical fluted pattern. Follow the instructions below to install the wall set on the chosen side.

1. Locate the ceramic rear wall in the channel at back of the firebox and flat against the back of the firebox.
2. Locate the sidewalls in the channels at the sides of the firebox.
3. Remove two screws from under the top front of the firebox. Using these screws fit the port cover.









Ceramic Logs Installation

1. Place the base log on the supports in the firebox and against the support at the firebox back.
2. Locate the rear upper log on the two ceramic pins at the rear of the base log.
3. Place the front log behind the metal strip at the front of the firebox.
4. Locate the right middle log on the pin in the right hand side of the base log .
5. Locate the left side log on the ceramic pin on the left hand side of the base log. Rest the narrow nose of this log on the projection at the front center of the base log—*ensure that the narrow nose does not rest on the burner.*
6. Locate the right side log on the pin in the front log and rest the nose of this log on the projection on the base log—*ensure that the nose does not rest on the burner.*




Ceramic Coals Installation

1. Place the base coal on the supports in the firebox and against the firebox back.
2. Place the left front coal in position behind the metal lip at the front of the firebox. The side projection on this coal should be near the middle front of the firebox.
3. Place the right front coal behind the metal lip at the front of the firebox. Its left side should rest over the projection on the left front coal.
4. The center right coal has letter "R" embossed underneath. Place this coal behind the front right coal.
5. The center left coal has letter "L" embossed underneath. Place this coal behind the front left coal.



Window Refitting and Checking

1. Place the window centrally against the engine unit and resting on the support at bottom front of the engine.
2. Pull the clamping bars forward and rotate inwards to secure the top of the window.
3. Fit the two spring loaded bolts through the bottom of the window and tighten to secure the bottom of the window.
4. Pull the top of the window forward and release to ensure the springs return it in position.
5. Similarly check the bottom of the window by pulling it forward and releasing.
6. Apply light hand pressure against the window frame sides to bed in the window seal.



Operation Checks

Check ignition, pilot stability, burner flames, and the full range of the thermostat using the rotary switch inside the appliance and the remote control. See the *Lighting Instructions* on page 30 of this manual for full details.

Aeration adjustment

As described on page 23, the burner aeration is adjustable. For the vast majority of installations, no adjustment will be necessary. However, in a very few instances, performance may be improved by adjusting the aeration by sliding the shutter. Evaluate the aeration only after the unit has warmed up—approximately 15 minutes.

The shutter setting is very sensitive. Small adjustments can make a substantial difference to the flames. We strongly advise that adjustments be made in steps of no more than 1/64" (0.4 mm).

Increasing aeration will cause the flame to appear more transparent and blue making the ceramic fuel effects glow more.

Decreasing aeration will cause the flames to appear more yellow or orange making the fuel effects glow less.

Too little aeration may result in black carbon forming and dropping into the firebox.

Owner's Information

Operating Your Fireplace

For your safety, this appliance is fitted with a flame supervision device which will shut-off the gas supply if, for any reason, the pilot flame goes out. This device incorporates a fixed probe, which senses the heat from the pilot flame. If the probe is cool, the device will prevent any gas flow unless the burner control knob is kept pushed in at the PILOT position. See the lighting instructions on page 30 of this manual.

Cleaning

It will be necessary to clean the glass periodically. During startup, condensation, which is normal, forms on the inside of the glass and causes dust and lint to cling to the glass surface. Initially, paint, while curing, may deposit a slight film on the glass. We therefore recommend that, during the first few weeks of use, the glass be cleaned two or three times with non-abrasive common household cleaners (such as dish soap) and warm water. **Ammonia based cleaners should NOT be used.**

Subsequently, the glass should be cleaned two or three times a season depending on the circumstances. Do not clean the glass while it is hot. Always securely replace the window before lighting. **If broken, the glass pane may only be replaced as a complete window unit as supplied by the manufacturer.**

To remove the window for cleaning, release its top by pulling forward and rotating outwards the two bars at the top corners. Unscrew the two spring-loaded bolts at the bottom of the window. Lift the window and set it aside with the bolts to avoid damage. See page 17.

To refit the window, place it centrally against the firebox while resting it on the support at the bottom of the firebox. Pull the clamping bars forward and rotate inwards to secure the top of the window. Fit the two spring-loaded bolts through the bottom of the window and tighten to secure. Pull the top of the window forward and release to check that the window opens slightly and returns in the event of a delayed ignition. Similarly, check the bottom of the window by pulling it forward and releasing. Then, apply light hand pressure against the window frame sides to bed-in the window seal. See page 26.

Dust can be brushed from the ceramic logs and firebox walls after removing the front unit and opening the window. Dust can also be removed from the burner using a soft brush after removing the ceramic logs. When cleaning, make sure that no particles are brushed into the slots of the burner.


Checks

A periodic check of the pilot and burner flames should be made. Check after the fire has been on for at least 30 minutes. The pilot flame must cover the tip of the thermocouple probe. The main burner flame pattern will vary from appliance to appliance depending on the type of installation and climatic conditions.




The appliance area must always be kept clear and free from combustible materials, gasoline and other flammable vapors and liquids.

Inspect the vent terminal outdoors regularly to make sure that dirt, snow, insects, leaves, shrubs, trees do not obstruct it.


Examine the whole vent system regularly. We recommend annually.



Performance of LPG appliances may be affected by the quality of commercial gas supplied in your area.



Correct flame appearance



Owner's Information

Batteries

All appliances use four 1.5V AA batteries for remote control receivers and the handset uses a 9V battery. Batteries are accessible by opening the bottom access panel and removing the lid of the remote control receiver. Batteries should last one to two seasons, depending on usage. Removing batteries in the off season will extend battery life.

Servicing

If you require any attention to your appliance, contact your supplier quoting the model number. It will be helpful if the appliance serial number can also be quoted. This is on the rating plate, which is on a chained, plate accessible by opening the bottom access panel.

The repair parts are shown in the separate repair parts leaflet. Please always quote part number and description when requesting spare parts.

Programmable Remote Control

Your fireplace remote control helps you get the comfort, convenience and aesthetics you want from your gas fireplace. The remote controls your fireplace in different ways.

IMPORTANT: *BEFORE YOU BEGIN*, please note that on this system, the settings of time, temperature and automatic ON/OFF **can only be programmed when the function display is flashing**. Be patient when programming as it can take a few seconds to set.

Setting the time

The first thing to do is to set the time.




1. With your thumb, hold down **both** the **AUTO** and **TIMER** buttons until **F** flashes. Let go.
2. Note the digital clock on the bottom right hand corner. The **▲** button sets the hour; the **▼** button sets the minutes. Set the time.
Note: You must start setting the time while the **F** is flashing. If it stops flashing, go back to 1.
3. The display shows °C/24-hour or °F/12-hour. To change the temperature/hour display, press on the **AUTO** button while the display flashes.
4. Let go and wait until the flashing stops. The remote shows the time you set. It also shows the current temperature.

Setting the temperature

Use this setting when you come in and want to enjoy a specific temperature.

1. Push the **AUTO** button until a number and **F** flash. Let go.
2. While it is still flashing, push the **▲** and **▼** buttons to the temperature you want. Let go.

Your fireplace will reach that temperature and the remote will check the temperature every five minutes, adjusting the amount of fuel needed to give you a steady, even heat.




Owner's Information

Setting the flame

Use this setting when you want a particular flame level. For instance, you want to watch flames burn at their highest level and you don't mind if the room is too hot.

1. To raise the flame, press and hold the ▲ button until the flame gets to the desired level. Let go.
2. To lower the flame, press and hold the ▼ button until the flame gets to the desired level. Let go.

The **flame level** will remain just as you set it.



Programming time and temperature

You can set your fireplace to come on before you wake up and turn off after you leave and then, turn on again just before you come home and turn off after going to bed.




You can leave it like this for the heating season.

1. Decide what temperature you want your fireplace to be at. Also, decide what time you want your fireplace to turn on and off. Finally, decide what time you want it to come back on and off in the afternoon or evening. For the first few times you set the timer, it's handy to write these times down.
2. Set the temperature (just as you did in the section *Setting the temperature*.)
3. Press the **TIMER** button and hold it until **P1** ☀ appears and flashes. Let go. While flashing, push the buttons ▲ (hour) and ▼ (minutes) to set the time at which you want your fireplace to turn on in the morning.
4. Press the **TIMER** button and hold it until **P1** ☾ appears and flashes. Let go. While flashing, push the buttons ▲ (hour) and ▼ (minutes) to set the time at which you want your fireplace to turn off when you leave.
5. Press the **TIMER** button and hold it until **P2** ☀ appears and flashes. Let go. While flashing, push the buttons ▲ (hour) and ▼ (minutes) to set the time at which you want your fireplace will turn back on in the afternoon.
6. Press the **TIMER** button and hold it until **P2** ☾ appears and flashes. Let go. While flashing, push the buttons ▲ (hour) and ▼ (minutes) to set the time at which you want your fireplace to turn off in the evening.
7. That is all you have to do. Your fireplace will give you steady, even heat at the temperatures and times you set.

Note: If you want to set your fireplace for only one time on and off, set **P2** ☀ and **P2** ☾ for the same times as **P1** ☾. The remote will record the **P1** ☾ off time for both **P2** times.

To temporarily override the timer setting, just press **AUTO** or ▲ and ▼ to go back to manual settings. Press **TIMER** to go back to your settings.

When your remote control displays **BATT**, you need to replace the battery with a new 9 volt alkaline battery—6LR61/MN1604.



Lighting Instructions

FOR YOUR SAFETY READ BEFORE LIGHTING



WARNING: If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.


- A. This appliance has a pilot, which must be lighted by hand. When lighting the pilot, follow these instructions exactly. To save energy, turn the pilot off when not using the appliance.
- B. **BEFORE LIGHTING** smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
 - Do not touch any electric switch; do not use any phone in your building.
 - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
- C. Use only your hand to push in or turn the control knobs. Never use tools. If the controls will not push in or turn by hand, don't try to repair them, call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control, which has been under water.



LIGHTING INSTRUCTIONS

1. **STOP!** Read the safety information above.
 2. Set the flame adjustment knob as far clockwise  as possible*.
 3. Turn the gas control knob clockwise  to OFF.
- NOTE: The knob cannot be turned from PILOT to OFF unless it is pushed in partially. Do not force.
4. Wait five (5) minutes to clear out any gas, then smell for gas, including near the floor. If you smell gas, **STOP!** Follow "B" in the safety information above. If you don't smell gas, go to the next step.



5. Find the pilot. It is at the left side of the firebox viewed through slotted hole in front log.
6. Push in and turn the gas control knob counterclockwise until resistance is felt just before the "IGN" position.
7. Keep pushed in for a few seconds to allow gas to flow then, keeping knob depressed, turn to "PILOT" to light pilot. Hold knob in for a further 5 seconds then release. The knob should pop back out. Pilot should remain lit. If pilot goes out repeat steps 3 through 7.
 - If knob does not pop out when released, stop and immediately call your service technician or gas supplier.
 - If pilot lights but will not stay lit after several tries, turn the gas control knob to "OFF" and call your service technician or gas supplier.
8. When pilot is lit, partially depress the knob and turn to "ON" position (Burner alight).
 - Do not leave knob set between "PILOT" and "ON".
9. Set the flame height to desired setting*.

TO TURN OFF GAS TO APPLIANCE

1. Set the flame adjustment knob as far clockwise  as possible*
2. Push in gas control knob slightly and turn clockwise  to "OFF". Do not force.

* The flame height can be increased or decreased by depressing the remote control hand set button.

Options

Additional optional features

Stone Effect Set #561SES

The Stone Effect set may be installed as a fuel bed instead of the logs or coals supplied with the engine. It may be fitted at the time of the engine installation or retrofitted at a later date.

Bedroom Remote Kit #562BRK

Automatic shut-off remote control kit for bedroom installation.

Circulating Fan Kit #555CFK

Having variable speed and temperature control, it is designed to boost the natural convection process through the appliance. It may be fitted before the fireplace is installed or retrofitted at a later date.

LPG Conversion Kit 554LPK

Burner & injector kit for conversion from natural gas to propane.

Approved Venting Components



Approved Alternative Direct Vent Suppliers for Valor Models 530, 534, 535, AND



Miles Fireplaces' Models RF24D and MF28

Venting Parts Description			Venting Parts Code / Availability by Manufacturer						
			SIMPSON DURA-VENT	SELKIRK		SECURE VENT	RLH INDUSTRIES	MILES INDUSTRIES	
Termination Caps	Horizontal	Co-axial kit, 26" long	—	—	—	—	—	551DVK	
		Standard Co-axial	984	4DT-HC	—	—	—	—	
		High Wind Co-axial	985	—	—	SV4CHC	—	—	
	Vertical	Standard Co-axial	980	4DT-VC	—	—	HSDV4658-1313		—
		High Wind Co-axial	991	—	—	SV4CGV	—	—	—
		Extended Co-axial	930	—	—	—	—	—	—
		Co-linear	—	—	—	3PDVCV	HS-C33U-99 HS-C33F-1313	559CLT	
		Snorkel, 14" Rise	982	4DT-ST14	—	—	—	—	—
	Snorkel, 36" Rise	981	4DT-ST36	—	—	—	—	—	
Vent Adapters / Couplers	Universal Adapter 3" Flex Coupler		2150	—	—	—	—	—	
	Co-linear Flex Connector		923F	—	—	—	—	—	
	Co-axial to Co-linear Adapter		923GCL	—	—	—	—	556CLA	
	Co-linear to Co-axial Adapter		923GK	—	—	—	—	—	
Aluminum Flexible Liner	3" Diameter		2280 Series	3" ACFL		NOTE: 2-ply liner approved to CAN/ULC S635 suitable for venting gas appliances. As manufactured by Z-Flex.			
Adjustable Pipe Length 4" x 6-5/8"	11" to 14-5/8"	Galvanized	911	—	—	—	—	—	
		Black	911B						
	12" to 17"	Galvanized	912	—	—	—	—	—	
		Black	912B						
	17" to 24"	Galvanized	917	—	—	—	—	—	
		Black	917B						
	4" to 10"	Galvanized	—	4DT-ADJ		—	—	—	
		Black	—	4DT-ADJ(B)					
	1-1/2" to 6"	Galvanized	—	—	—	—	—	SV4LA	
		Black	—					SV4LBA	
	1-1/2" to 12"	Galvanized	—	—	—	—	—	SV4LA12	
		Black	—					SV4LBA12	
	1-1/2" to 24"	Galvanized	—	—	—	—	—	SV4LA24	
		Black	—					SV4LBA24	

Approved Venting Components

Venting Parts Description		Venting Parts Code / Availability by Manufacturer						
		SIMPSON DURA-VENT	SELKIRK		SECURE VENT	RLH INDUSTRIES	MILES INDUSTRIES	
DV 45° Elbows	Galvanized	945	—	—	—	—	—	
	Black	945B	—	—	SV4EBR45	—	—	
	Galvanized Swivel	945G	4DT-EL45	—	SV4E45	—	—	
	Black Swivel	945BG	4DT-EL45(B)	—	SV4EB45	—	—	
DV 90° Elbows	Galvanized	990	—	—	—	—	—	
	Black	990B	—	—	SV4EBR90	—	—	
	Galvanized Swivel	990G	4DT-EL90	—	SV4E90	—	—	
	Black Swivel	990BG	4DT-EL90(B)	—	SV4EB90	—	—	
Pipes 4" x 6 5/8" (ID x OD)	6" long	Galvanized	908	4DT-06	—	SV4L6	—	—
		Black	908B	4DT-06(B)	—	SV4LB6	—	—
	9" long	Galvanized	907	4DT-09	—	—	—	—
		Black	907B	4DT-09(B)	—	—	—	—
	12" long	Galvanized	906	4DT-12	—	SV4L12	—	—
		Black	906B	4DT-12(B)	—	SV4LB12	—	—
	18" long	Galvanized		4DT-18	—	—	—	—
		Black		4DT-18(B)	—	—	—	—
	24" long	Galvanized	904	4DT-24	—	SV4L24	—	—
		Black	904B	4DT-24(B)	—	SV4LB24	—	—
	36" long	Galvanized	903	4DT-36	—	SV4L36	—	—
		Black	903B	4DT-36(B)	—	SV4LB36	—	—
	48" long	Galvanized	902	4DT-48	—	SV4L48	—	—
		Black	902B	4DT-48(B)	—	SV4LB48	—	—
	Flashing	Roof Flashing 0/12-6/12	943	4DT-AF6	—	SV4FA	—	—
		Roof Flashing 7/12-12/12	943S	4DT-AF12	—	SV4B	—	—
Flat Roof Flashing		943F	—	—	SV4F	—	—	
Various Venting System Parts	Wall Thimble	942	4DT-WT	—	SV4RSM	—	—	
	Storm Collar	953	4DT-SC	—	SV4AC	—	—	
	Decorative Plate	940	4DT-CS	—	SV4PF	—	—	
	Cathedral Ceiling Support	941	4DT-CCS	—	—	—	—	
	Ceiling Firestop /Floor Support	963	4DT-FS	—	SV4BF	—	—	
					SV4SD			
	Wall Strap	988	4DTWS	—	—	—	—	
	Vinyl Siding Standoff	950	4DT-VS	—	SV4VS	—	—	
	Elbow Strap	989	4DT-OS	—	—	—	—	
Terminal Guard	984SG	—	—	—	—	835TG		

Notes: 1) Simpson Dura-Vent co-axial pipes and fittings require Valor 817VAK Starter Adapter to fit Valor's smooth collars. All other above manufacturers' collars will fit directly to Simpson Dura-Vent or Valor's smooth collars. 2) Follow instructions supplied with each manufacturer's components. 3) Unless otherwise specified, all the parts and assemblies from the above table are to be used with 4" x 6-5/8" pipes. 4) Termination caps manufactured by RLH Industries are from *Homestyle Chimney Collection* and can be ordered in one of the following finishes: a) aluminium; b) black powder coated; c) solid copper.

Warranty

If you have a problem with this unit, please contact your dealer or supplier immediately. Under no circumstances should you attempt to service the unit in any way by yourself. The warranties in paragraphs 1 and 2 are provided only to the first purchaser/user of this unit, are not transferable and are subject to the conditions and limitations in paragraphs 3, 4 and 5. Please review the conditions and limitations carefully and strictly follow their requirements.



1. Extended Warranty Coverage

For a period of up to ten (10) years, Miles Industries Ltd., (the "Company") or its appointed distributor will at its option pay the initial purchaser for the repair of, or will exchange the following parts or components which are found to be defective in material or workmanship under normal conditions of use and service:

Part or Component	Defect Covered	Maximum Warranty Period
Exterior steel casing	Corrosion	10 years
Glass	Loss of structural integrity	10 years
Cast iron parts	Corrosion	10 years
Firebox and heat exchanger	Corrosion (but not discoloration) causing loss of structural integrity	10 years

2. Two-Year Parts Warranty

In addition, for two (2) years from the date of purchase, the Company, at its option, can repair or exchange all parts and components not listed above but that are found to have a *bona fide* defect in material or workmanship under normal conditions of use.

3. Conditions and Limitations

- a) The warranty registration card must be completed by the initial owner and returned to the Company within 90 days of purchase.
- b) Installation and maintenance must be performed by an authorized and trained dealer in accordance with the Company's installation instructions.
- c) This warranty is void where installation of the unit does not conform to all applicable codes including national and local gas appliance installation codes and building and fire codes.
- d) The owner must comply with all operating instructions.
- e) The Company is not responsible for the labor costs to remove defective parts or re-install repaired or replacement parts.
- f) The first purchaser or user of the unit will be responsible for any shipping charges for replacement parts as well as travel time incurred by the dealer to perform the warranty work.
- g) This warranty applies to non-commercial use and service and is void if it is apparent that there is abuse, misuse, alteration, improper installation, accident or lack of maintenance to the unit.
- h) This warranty does not cover damage to the unit through:
 - i) Improper installation, operational or environmental conditions.
 - ii) Inadequate ventilation in the area or competition for air from other household equipment or appliances.
 - iii) Damage due to chemicals, dampness, condensation, or sulphur in the fuel supply lines which exceeds industry standards.
- i) This warranty does not cover glass, log breakage or damage to the unit while in transit.
- j) The Company does not allow anyone to extend, alter or modify this warranty and assumes no responsibility for direct, indirect or consequential damages caused by the unit. State or provincial laws where the first purchaser or user resides may provide specific rights to extend this warranty and, if so, the Company's sole obligation under this warranty is to provide labor and/or materials in accordance with those laws.

4. Discharge of Liability

After two (2) years from the date of purchase, the Company may, at its option, fully discharge all obligations under this warranty by paying to the first purchaser/user the wholesale price of any defective parts.

5. No Other Warranty

All obligations to repair this unit are defined in this warranty. Some states or provinces may specifically mandate additional warranties on the part of manufacturers, but in the absence of such specific legislation, there is no other warranty or obligation expressed or implied.

Replacement Parts

Code	Description	Part no.	Code	Description	Part no.
1	Side wall support (2)	330A898	36	Elbow injector NG/LPG	720A580 / 9730013
2	Rear wall support	320B320	37	Inlet pipe	030A224
3	Battery shield	330A908	37a	Inlet pipe adapter	220K997
4	Velcro strip	4000022	37b	Valve to inlet pipe connector	220K891
5	Brick retainer	4000828AH	38	Pilot pipe	030A226
6	Inner vent collar	340B174	39	Snap off olive nut	220K913
7	Inner vent collar seal	620B973	40	Window support	320B399
8	Top vent collar seal	568399	41	Valve unit assy incl. 42/43/44	4000251
9	Top vent cover plate	330A902	42	Valve to main burner pipe connector	220K891
10	Wall bracket spacer (2)	320B360AZ	43	Valve cover	4000801
11	Outer vent collar seal	568399	44	Pilot ignition wire	700K736
12	Outer vent collar	330A888	44A	Servo motor	4000802
13	Restrictor plate #6 (coals)	320B463	45	Remote receiver	4000328
14	Restrictor plate #5 (coals)	320B458	46	Hand held control	4000327
15	Restrictor plate #4 (coals)	320B457	47	Wall mount plate	9000008
16	Restrictor plate #1 (logs)	320B396	48	Wiring harness	4000329
17	Restrictor plate #2 (logs)	320B397	49	Ceramic coal set	000B245
18	Restrictor plate #3 (logs)	320B405	50	Centre left coal	640K615
19	Window unit	050A216	51	Base coal	650K237
20	Spring loaded bolt (2)	000B214	52	Centre right coal	640K616
21	Burner unit incl. #22 NG/LPG	3000025 / 740K185	53	Front right coal	640K618
22	Aeration shutter assy NG	4000682 / 3000220	54	Front left coal	640K617
22	Aeration shutter LPG	568559	55	Ceramic log set	4000162
23	Pilot unit complete NG/ LPG	4000062 / 4000063	56	Right middle log	4000372
24	Pilot injector NG/LPG	720A575 / 720A195	57	Right side front log	4000470
25	Thermocouple	4000061	58	Front log	4000370
26	Hooked olive for pilot	720A196	59	Base log	4000368
27	Electrode	720A543	60	Left middle side log	4000371
28	Electrode nut	720A200	61	Rear log	4000369
29	Olive nut for pilot	420K385	62	Ceramic reversible walls set	4001160
30	Pilot shield	4000144			
31	Pilot support bracket	330A904			
32	Main burner pipe	030A225			
33	Olive nut	220K567			
34	Olive	420K342			
35	Base support bracket (2)	330A894			

Replacement Parts

