

HOME WIFI GUIDE

In-home setup and minimum system requirements.

Introduction

Valor L1, L1 See-Thru, L2, L3, LX1, and LX2 gas fireplaces can be installed or upgraded with a WiFi module, allowing you to connect the fireplace onto the home's WiFi system and control it using the Valor 10 app on a smart device.

Take full control of with intuitive and interactive options—including the ability to program, set a timer, or integrate child safety locks.

Getting Started

To ensure that the installation of your Valor 10 WiFi system goes smoothly, follow these steps to prepare your home before your authorized Valor dealer installs or upgrades your fireplace. Please note the minimum system requirements for optimal performance.



In-Home Setup

- Must have an internet connection.
- Must have wireless router, located close to the room with the fireplace. Be prepared to add a WiFi repeater if signal strength at the fireplace location is weak.
- Have your home WiFi password on hand.
- Ensure that your smartphone and or tablet device can run the Valor 10 App. Download to device before installers arrive.
- Have 120v AC power available at the fireplace installation location to power V-module.

Minimum System Requirements

- Supports Apple iOS 6.0 or later and Android 4.2 and up.
- App takes up 60.3 MB for Apple/iOS and 19 MB for Android.
- An internet connection is necessary for the app to control the fireplace(s).
- SSID Address (home WiFi networ) & password are needed.
- Controlling smart device must use home WiFi network (can not be controlled from network outside of the home).
- Can control up to 8 gas fireplaces. Each fireplace requires a separate WiFi receiver.

Search for "Valor 10" or "Valor 10 Remote" on the Apple App Store or Google Play Store to download the free app. Enjoy!



